# 中文

# MZ-360 蓝牙音箱

# 安装指南

感谢您购买本产品。使用蓝牙音箱前,请阅读所有安全信息和操作说明。

## 安全须知

иша°

- 阅读所有说明,并保存起来以各日后参考。
- 请遵循产品操作的所有说明。
- 长期暴露在阳光和高温下。
- ●此音箱有3种模式:蓝牙模式,AUX模式和TF卡模式。
- ●请注意: 当音乐暂停30分钟后, 音箱将进入休眠关机。 要重新启动音箱, 请按 电源开/关/模式按钮。

## 包装内容

自行车支架 ● 0.6m USB充电线

# 93mm/3.66in \_\_\_ 86mm/3.38in

● 🕲: 电源开/关/模式: 关机状态长按1秒开机: 开机状态长按1秒关机: 开机

❷ ◆: 增加音量/下一曲: 长按按钮音量加。 短按按钮下一首 (蓝牙模式和TF

⑥ ▶:播放/暂停/配对:在音箱蓝牙连接状态,或TF卡模式下,短按此按钮可

④ ➡: 降低音量/ ├一曲: 长按按钮音量减。 短按按钮 ├一首(蓝牙模式和TF)

以播放/暂停;在音箱蓝牙连接状态下,长按按钮1秒,强制断开当前连

♠ 电源接口: DC 5V 1A

- ●请勿将其放置在热源附近。 避免使用散热器,火炉和其他会发热的设备。 避免

- MZ-360 = 机。

卡模式下有效)

控制面板和界面

状态短按此按钮切换模式。

接, 讲入蓝牙搜索配对状态。

 $\Theta \Phi \Phi \Phi$ 

- 卡模式下有效) ♠ AUX輸入接口
  - 电源/充电指示灯(蓝/红灯 夏 麦克风

• 充电时长: 2.5-3/小时 工作时长: 60%音量连续工作10小时 • 待机时长: ≥300小时

• 工作电压: 5V/1A 额定功率: 5W 蓝牙范围: ≤10m • 频率响应: 20HZ-20KHZ

 防水等级: IPX7 电池容量: 750mAh

### 操作指令

蓝牙版本: V5.3

长按电源按钮1秒,开机,有开机提示音。 开机后,电源指示灯(蓝灯)常亮 3 秒后 进入闪烁状态, 音箱进入与手机蓝牙搜索 配对状态, 默认音量80%, 每次打开音 箱后, 音箱都会自动恢复默认音量80%,



- A.当音箱关闭时,仅插入TF卡或同时插入TF卡和音频电缆时,打开音箱后,音箱 将首先进入TF卡模式。 若要切换至BT模式,您可以短按电源按钮,音箱可切换
- 至BT模式,并进入配对状态。 B.当音箱关闭且连接了音频线时,打开音箱后,音箱将首先进入AUX模式。 若要
- 切换至BT模式,您可以短按电源按钮,音箱可切换至BT模式,并进入配对状态。 C. 当音箱关闭时,未插入TF卡目未连接音频线时,音箱将在打开后直接进入BT模
- D.当音箱打开时, 音箱将进入与最后连接的输入 (TF卡或音频电缆) 相对应的模 式。 若要切换至BT模式, 您可以短按电源按钮, 音箱可切换至BT模式, 并进入 配对状态。

### 打开手机或其他蓝牙设备上的蓝牙功能,然后搜索名为MZ-360的音箱。与音

箱连接。 1.在手机上搜索MZ -360音箱:

2.连接MZ -360音箱: 3.选择通过MZ -360音箱播放音乐。

指示灯

配对成功后,会有提示音,蓝色指示灯将常亮。

在手机上播放音乐。播放音乐时,蓝色指示灯将慢闪,音乐暂停时,蓝色指示

## 步骤5

● 步骤2

步骤3

如何将音箱与新设备连接:


将音箱与设备连接时,您可以长按播放/暂停/配对按钮以切断当前连接并进入 配对状态。然后,蓝色电源指示灯将快闪,音箱可以与新设备连接。




如果转向轴太细目不能仅用1个防滑垫固定,则可以将垫1和2放入环中,使转向 轴穿过环,然后用螺钉拧紧支架。 如果支架仍然松动,则可以折叠防滑垫2,然 后将防滑垫1和折叠垫2放入环中,使转向轴穿过环,然后用螺钉拧紧支架。

# 支架安装指南

如图1所示,按下支架的 凸起部分,取出音箱,然 后再安装支架。



如图2所示,从支架上拧



下螺钉。

将防滑垫1放入支架的环中,将支架通过环固定到自行车上,然后用在步骤2中 取出的螺钉拧紧支架。



● 步骤4

安装支架后,您可以将音箱推入支架。 听到咔哒声后, 音箱就安装好了。



## 蓝牙音箱连接记忆功能

如果设备蓝牙功能开启,打开音箱后,音箱将自动连接到最后一个配对设备。


### 蓝牙音箱通话功能

- ●接听电话: 当音箱与手机连接时,如果有来电,您可以短按播放/暂停按钥即可
- 挂断电话: 当音箱与手机连接时,通话中 您可以短按播放/暂停按钮即可挂断。





▼末号重播: 当音箱与手机连接时, 您可以通过短按播放/暂停按钮两次来拨打您 最后拨打的电话号码。



在AUX模式下,播放音乐时,蓝色指示灯将慢闪,在静音模式下,蓝色指示灯

### TF卡模式

可以短按电源按钮进入模式切换。

通过AUX端口插入3.5mm音频线。以

插入TF卡后,音箱将进入TF卡模式,



在TF卡模式下,当播放音乐时,蓝色指示灯将慢闪,音乐暂停时,蓝色指示灯

充电指示灯充电时,红色指示灯将常亮,并且在音箱充满电后将熄灭。

保修卡

# 保修记录

故障描述 维修人员签字

购买日期

用户姓名

电子邮件

合格证

检验员: \_\_\_\_\_

### *lnwa*° English

# MZ-360 Wireless Speaker

# INSTALLATION GUIDE

Thank you for buying this product. Please read all safety information and operation instruction before using the bluetooth speaker.

# SAFETY INSTRUCTIONS

- Read all instructions and save them for personal reference in the future.
- Follow all directions for operating the product.
- Do not set up near heat sources. Avoid radiators, stoves, and other devices that produce heat. Avoid long-term exposure to sunlight and high temperatures.
- There are 3 modes for this speaker: Bluetooth Mode, Audio Mode and TF Card
- Please note: When the music is paused for 30 minutes, the speaker will enter into Sleep Mode. To restart the speaker, please press Power ON/OFF/Mode.

## PACKAGE CONTENTS

MZ-360 speaker

- Speaker holder for bicycles 1m audio cable X1
- 0.6m usb charging cable

### PRODUCT DESCRIPTION PRODUCT PARAMETERS

. Working hours: 10h battery life . Standby time: >300 hours

86mm/3.38in

- Bluetooth range: ≤10m
- Frequency: 20HZ-20KHZ

at 60% volume

Bluetooth version: V5.3

- . Charging time: 2.5-3 hours
- Rated power: 5W
- Battery capacity: 750mAh

### OPREATION INSTRUCTION

Long press the power button, the speaker will be turned on after hearing the prompt tone. The power indicator light will turn blue and on for 3 seconds. Afterwards, the blue light flashes quickly,

indicating the speaker is entering Pairing mode Please Note: The set volume is 80%. Each time you turn on thespeaker, it will be at 80% volume automatically.



- 2 1: Volume UP/Next: Long press the button to increase the volume. Short press the A. When the speaker is off, with only TF card inserted or with both TF card inserted and button to move to the next song(only function in Bluetooth Mode & TF Card Mode). Audio cable connected, the speaker will enter TF card Mode first after turning it on. To swift to BT Mode, you can short press the Power Button, and the speaker can
- 3 >: Play/Pause/Pairing: In Bluetooth Mode or TF Card Mode, short press the button to play or pause music. In Bluetooth Mode, long press the button to cut the current enter Pairing status. Bluetooth connection and enter Pairing status.
- ④ ⇒ :Volume Down/Prev: Long press the button to lower the volume. Short press the button to move to the previous song(only function in Bluetooth Mode & TF Card

Inwa

Power Port: DC 5V 1A

Power ON/OFF/Mode: Long press the button to turn on/off the speaker.

When the speaker is on, short press the button to swift mode of the speaker.

Indicator Light Microphone

93mm/3.66in

CONTROL PANEL AND INTERFACE

\_\_\_

-0-0

- Working voltage: 5V/1A
- IP rating: IPX7

be onconstantly.

B. When the speaker is off, with Audio cable connected, the speaker will enter AUX Mode first after turning it on. To swift to BT Mode, you can short press the Power Button, and the speaker can enter Pairing status.

C. When the speaker is off, with no TF card inserted and no Audio cable connected, the speaker will enter Bluetooth Mode directly after turning it on.

### D. When the speaker is on, the speaker will enter the corresponding mode to the last connected input(either TF card or Audio cable). To swift to BT Mode, you can short press the Power Button, and the speaker can enter Pairing status.

### Step 2

with the speaker.

Step 3

Turn on the Bluetooth function on your phone or other Bluetooth devices and search for our speaker which is named as MZ- 360. Connect



After pairing successfully, there will be a prompt tone and the blue indicator light will

### Step 4

1. Search for MZ -360 Speaker on your phone:

3. Select playing music via MZ -360 Speaker.

2. Connect with MZ -360 Speaker:

Play music on the phone. When the music is playing, the blue indicator light will flash slowly, and when the music is paused, the blue indicator light will be steady on.

### Step 5

How to Connect the Speaker with a New Device:

When the speaker is connected with a device, you can long press the button PLAY/ PAUSE/PAIRING to cut the current connection and enter Pairing status.


Then the blue power indicator light will flash quickly, and the speaker can connect with a new device.



# INSTALL ATION GUIDE OF HOLDER


## Step 1

As picture 1 shows, pressing the bulge of the holder, takeout the speaker before installing the holder.




## Step 2

As picture 2 shows, screw or the screws from the holder.



### Step 3


Put the non-slip mat 1 into the ring of the holder, fix the holder onto the bike through the ring, and tighten the holder with screw which has been taken out in step 2.



If the steering axle is too thin and can not be fixed with only 1 non-slip mat, you can put mat 1 & 2 into the ring, pass the steering axle through the ring, then tighten the holder with screw. If the holder is still loose, you can fold the non-slip mat 2, and put the mat 1 & folded mat 2 into the ring, pass the steering axlethrough the ring, then tighten the holder with screw.

### Step 4 After installing the holder, you can push the

speaker into the holder. Upon hearing a click, the speaker is installed well.



## CONNECTION MEMORY FUNCTION OF THE SPEAKER

 The speaker will automatically connect to the last paired device, in case that BT function of the device is on, after turning the speaker on.

### TEL FUNCTION OF THE SPEAKER

- Pick up Phone Call: When the speaker is connected with phone, in case of a coming call, you can pick up the call by short pressing the PLAY/PAUSE button.
- Hang UP: When the speaker is connected with the phone, you can hang up by short. pressing the PLAY/PAUSE button.
- Reject a Call: When the speaker is connected pressing the PLAY/PAUSE button.
- Redialing the Last Call: When the speaker is connected with the phone, you can dial the last person you have talked on the phone by short pressing the PLAY/PAUSE

- with the phone, you can reject a call by long
- button twice.

AUX MODE

TF CARD MODE

The speaker will enter TF Card Mode after

inserting TF card, and you can short press

will go out when the speaker is fully charged.

Need further help, you can contact us by

Service E-mail: inwa\_support@innosystemtech.com

the Power Button to swift modes.

Insert 3.5MM LINE IN cable via the AUX port to swift to the AUX Mode. You can press the Power Button to swift modes.

in the mute mode, the blue indicator light will be on constantly.

In TF Card Mode, when the music is playing, the blue indicator light will flash slowly.

When the charging indicator is charging, the red indicator light will be steady on and

SUPPORT INFORMATION

and when the music is paused, the blue indicator light will be on constantly.





In AUX Modes, when the music is playing, the blue indicator light will flash slowly, and

SUCCESS COURIER SL



Madrid 28947 Spain

manufacturers/importers/distributors for the product, nor involved in the

OST UK 20230424000006 goalservice@hotmail.com

UK REP OFFICE 1029 3 HARDMAN STREET 10TH

GOAL REACH CONSULTING LTD

LOOR, SPINNINGFIELDS MANCHESTER.

We simply act as UK representative for cross-border sellers, and are not manufacturers/importers/distributors for the product, nor involved in the

manufacture/import/sale of the product. Therefore, we are not responsible for any after-sales services related to

the product. In case of any product quality or infringement issues, the manufacturer/importer/seller shall be solely held responsible.



OST EU 20230424000022 successservice2@hotmail.com

We simply act as EU representative for cross-border sellers, and are not

manufacture/import/sale of the product.

Therefore, we are not responsible for any after-sales services related to

the product. In case of any product quality or infringement issues, the manufacturer/importer/seller shall be solely held responsible.